

EXP NO:4

STUDY OF LAN CONFIGURATION

DATE:

AIM:

To study the setup and configuration of LAN (Local Area Network) using a switch and Ethernet cables.

PROCEDURE:

1. Plan and design an appropriate network topology with respect to network requirement and equipment location.
2. **Apparatus Required:** 4 computers, a switch with 8, 16, or 24 ports, and 4 Ethernet cables.
3. Connect the computers to the switch and the Ethernet cables by plugging one end of the network cable to the computer and the other end to the switch.
4. **Assign IP address to the PCs.**
 - **a.** Hold **Windows + R** and type `ncpa.cpl`.
 - **b.** Right-click on **Ethernet** → **go to Properties** → **select Internet Protocol (TCP/IP)** → **go to Properties**.
 - **c.** Here change the values of **IP address and subnet mask**.
5. **Configure network switch:**
 - **a.** Ensure computer is connected to the network switch.
 - **b.** Open the web browser and type the IP address of the switch, then enter username and password to login.
 - **c.** Set up a new IP address.
6. Check the connectivity between switch and other machines by using the **ping command** in Command Prompt.
7. Select a folder and share it across computers connected in the LAN.
8. Access the shared folder in the different computer.

RESULT:

Thus, Local Area Network (LAN) setup and configuration was studied.